



The **Axia Wireless Nursing Call Station** annunciates up to 48 device ID's including wireless patient and pull stations, personal pendant transmitters, and other security and healthcare devices. Wireless consoles provide an audible tone and visually display the room number and name needing assistance. Add wireless emergency pull stations in bathrooms, dome lights over the doors, or code blue stations for priority emergencies. Exam rooms can be equipped with wireless flush mounted stations with one to 3 colored LED buttons to signal staff when assistance is needed.

Standard Features

- 900 MHz spread spectrum technology
- Alarm calls reset at the source
- Easy user programming
- 2 line by 16 character LCD display
- Six programmable relays
- All devices fully supervised
- User replaceable long-life battery
- Plug and play installation
- Supports up to 48 transmitters
- Audible and visual alerts



* Accessories Sold Separately

Equipment Options

- Wireless Single & Dual Bedside Stations
- Wireless Emergency Pull Stations
- Wireless Pendant & Wrist Transmitters
- Wireless multi-button LED stations
- Wireless Door & Window exit sensors
- Wireless Temperature sensors
- Smoke/Motion/Glass breakage sensors

